

HOLES TEMPLATE

Instructions:

1. Print this drawing on a 8.5x11 in paper; and make sure the "Actual Size" is selected under "Page & Size Handling" section.
2. Place the drawing and tape-it on the baseboard.
3. Drill the three holes on the drawing using a 7/64" drill bit.
4. Remove the drawing and proceed to install the dyno on the baseboard.

Required Materials:

- (1) Safety Glasses
- (1) Drill or Dremel
- (1) Masking Tape
- (1) Baseboard: 12in x 12in x1in
- (1) Drill Bit: 7/64"
- (3) Screws: #8 X 3/4" (included in every kit)

