


ELECTRIC MOTOR DYNO

Firmware Update Guide

V1.6



MINIPRO

FIRMWARE UPDATE

What is NEW for Version 1.6?

- New 100D Steel Flywheel
- New Current Sensor Boards Library

1


Enter Setup Mode



- 1.1. Change *only* Switch #8 to ON.
- 1.2. Press the Reset button on the board.
- 1.3. Open miniPRO Settings Application.



NOTE: Make sure you installed the latest application of miniPRO Dyno before you continue.



Electronic Board


2

Establish a Connection



3

Update the Firmware of your electronic




- 3.1. Select "Update Firmware."
- 3.2. Locate the latest firmware you like to install.
- 3.3. Select "OK" to continue with the update.
- 3.4. Select "OK" after the update is completed.
- 3.5. Do not change any settings. You must perform a factory reset.

NOTE: Go to--> support.miniprousa.com
To download the latest software and firmware.

4

Perform a Factory Reset



- 4.1. Select "Factory Reset."
- 4.2. Select "OK" to continue.
- 4.3. Select "OK" to after factory reset is completed.
- 4.4. Modify your dyno settings.
- 4.5. Select "Save" to complete your settings.
- 4.6. Select "Disconnect."
- 4.7. Change *only* Switch #8 to OFF.
- 4.8. Press the reset button on the board.

5

Done!

If you have any questions, please open a ticket.

miniPRO
ELECTRIC MOTOR DYNO

www.miniprousa.com

© 2018 miniPRO, LLC. All Rights Reserved.